VARYTEC

User’s Manual



VARYTEC LED SIGN

„OPEN“

Table of Content

1. Safety instructions 3
2. Installing 4
3. Technical Specification 4

1. Safety instructions

FOR SAFE AND EFFICIENT OPERATION

Be careful with heat and extreme temperature. Avoid exposing it to direct sunlight or near a heating appliance. Do not operate the device in a temperature below 41°F /5°C, or exceeding 95°F /35°C.

Keep away from humidity, water and dust. Do not place the device in a location with high humidity or lots of dust. Containers with water should not be placed on the device.

Keep away from sources of hum and noise such as transformer motor, tuner, TV set and amplifier.

Do avoid placing on un-stable location select a level and stable location to avoid vibration.

Do not use chemicals or volatile liquids for cleaning. Use a clean dry cloth to wipe off the dust, or a wet soft cloth for stubborn dirt.

If the device does not work properly, contact your sales agency immediately. If any troubles arise, remove the power plug immediately, and contact an engineer for repairing, do not open the housing because this might result a danger of electric shock.

Take care with the power cable. Never pull the power cable to remove the plug from the receptacle, be sure to hold the plug. When not using the device for an extended period of time, be sure to disconnect the plug from the receptacle.

2. Installing

When unpacking the device, please make sure that all items have been delivered. If something is missing, please contact your VARYTEC sales agency.

Before using the VARYTEC LED sign for the first time please make sure that no damages have occurred due to transportation.

If the housing or the cable is damaged, do not connect the device to the receptacle. Do not use the device before your VARYTEC sales agency repaired the damage.

Remove all packing material.

Securely plug the adapter into the adapter hole (marked “DC 6V 1000ma”) on the side of the LED sign.

There are two methods to mount the device: Hang with chains included or hang with screws, using the holes provided on the back of the device.

Select the method most stable for your location.

Once the sign is securely mounted, please connect the other side of the power adapter to the receptacle.

On the side of the LED sign, you will see an on/off switch. You can choose the steady or chasing mode. Chasing lights will go around the frame to attract more attention.

3. Technical Specification

Power supply:	**Max. 230/240V/AC, 50Hz**
Power consumption:	**Max. 600W**
Dimensions (L x W x H):	**890x330x520mm**
Weight:	**23 kg**

Made in China

Importer:

B & K Braun GmbH

Industriestraße 1

D-76307 Karlsbad

www.bkbraun.com

info@bkbraun.com